

Official 2011 Rules

Classic Antiques

Classes

Farmer Stock Tractor Pull

4300# 6650#

Drivers meeting 15 minutes before pull starts.

4900# 7150#

Tractors must weigh in 45 minutes prior to start.

5500# 8650#

Tractors must be registered ½ hour prior to start time.

6150# 8651-10,500#

Classes are 1959 & older; unless the same model is newer but made in 1959.

--Rules--

1. \$15 - \$20 Hook up fee per pull – **May Vary**
2. Tractors must be operated with hand throttle as came from factory.
3. All engines must have properly functioning governor. RPM must be no more than 10% over factory setting. Stock block or equivalent replacement for that model tractor (TSC powerblock, M&W Pistons, etc.) Naturally aspirated (Exceptions: Oliver Super 99GM, John Deere 435 GM.) No nitrous bottles.
4. All tractors pull in 1st gear unless otherwise instructed at drivers meeting. Open class tractors may be required to start in 2nd gear. No shifting while pulling. No pulling of torque (torque may be place in or out before pulling).
5. Hitches – maximum of eighteen inches (18”) height (stationary in all directions), locked at eighteen inches (18”) on tractors such as IH 2pt., Ford 3pt., etc. Must use factory equip. draw bar and mounting. Operator must furnish twisted clevis or bolt-on plow loop (factory or custom made) with three inch hole. Clevis or loop may be shimmed to achieve eighteen inches (18”) in height. **Wheelie bars are optional.**
6. Original hubs and wheels: OEM or equivalent replacement.
7. Tire sizes: 15.5 x 38 or smaller 7150# class and under – exception of larger factory stock. **Tire size above 15.5 will pull in the 8650# class or in the Heavy class.**
8. No Radial tires, no cut or tampering of tires.
9. No steel wheels allowed. No duals.
10. Front wheel weights and fluid will be allowed
11. **May have up to Four (4) bolt on rear wheel weights per side and up to 400 lbs. of suitcase weights.** Suitcase weights must be attached by bracket or bolted/strapped on. They must not extend out past the front frame of tractor nor the rear axle of tractor. **No front weight brackets allowed.**
12. Each tractor will have two (2) chances to start sled within 50 feet (50’).
13. No aggressive starts (ex. Pulling skid plate of sled off the ground).
14. All tractors operated in an unsafe manner on or off the track will be disqualified
15. Drivers must remain seated at all times & have one hand on the steering wheel while pulling.
16. Persons 16 years of age or younger must have signed parental consent.
17. Appearance- Stock: other than stated in the rules or only items in parts book for that model tractor allowed or items must bolt on with no additional modifications. Exception: Seat (TSC or other in stock mounting) Power steering (Char Lynn or other after market), Straight pipe.
18. The front end of tractor may not rise off the ground more than knee high.
19. If a tractor wins twice in two consecutive appearances the tractor will be moved up one class. Then if the tractor places in the top 3 out of at least 5 places the tractor will remain in that class until not placing in the top 3 out of at least 5 tractors. Tractors may weight up to that class with suitcase weights.
20. If any tractor part falls off while pulling/hooksing will result in disqualification.
21. One (1) tractor may pull 1 time. **This may be changed at the discretion of the local pull committee.**
22. Cheating * Forfeit Premium * 1 pull suspension * Agreed upon by committee.
23. Once a tractor is weighed a CERTIFICATION CARD will be issued and must be presented at each pull.
24. All tractors are subject to random scale check and RPM check.
25. **All decisions made by Judges and Local Pull Officials are final.**